



HOUND HEATER MOUNTING TEMPLATE

PLEASE READ ALL INFORMATION

Place template corner in the upper corner of your dog house so the cord hole to be drilled is approximately 11" down and 7" over from the upper corner of the house. (Tape down template)

** The basic measurements are 11 inches down and 7 inches over from the upper corner.

Please read this information carefully

Thermostat Use:

Turning the thermostat clockwise will increase the temperature setting of the Hound Heater Furnace.

Approximate settings are as follows:

LOW - MEDIUM is approximately 35F - 50F

MEDIUM - HIGH is approximately 50F - 80F

- ** All temperatures are dependant upon the size of the house, insulation, outside temperatures and if the house has a door. They are APPROXIMATE amounts and vary with every pet house!!
- ** NOTE: It is important that you monitor your individual house to achieve the desired temperature.
- ** Mount the heater with 3 *wood screws* (or *machine screws* with nuts for "Igloo Style" houses) - **not included**. Be sure the cord is not pinched when completing the mounting.
- ** Mount the heater with the flat side up (top) and the slant towards the floor.
- ** Mount the heat shield approximately 1-2 inches directly above the heater.

WARNING: The unit **MUST be mounted on a side wall. Mounting on the ceiling may cause the Hound Heater to fail and cause permanent damage!!

**NEVER MOUNT THE HOUND HEATER
ON THE CEILING OR FLOOR!!**

Drill a 1-1/8" dia. hole for the cord

